



1.0 General Product Information

The FOSC ACC universal aerial clamp-2 kit provides materials required to attach any FOSC 400 or 450 splice closure to a strand.

Important: Read and follow all safety precautions and warnings documented in the FOSC 400 and FOSC 450 closure Installation Instructions.

2.0 Kit Contents

- 2 large hose clamps
- 2 long steel straps
- 2 brackets with steel mounting hardware
- Installation instructions

3.0 Installation Instructions

1. Attach lashing wire clamps to bracket, then attach bracket to strand (Fig. 1)
2. Secure closure to bracket using stainless-steel hose clamps or steel straps (hose clamp or strap goes through slot in bracket as shown in Fig. 2).
3. Install the second hose clamp or strap near the end of the closure, as shown in Figs. 3 through 5.




Fig. 1




Fig. 2




Fig. 3: FOSC 400 B closure




Fig. 4: FOSC 400 A closure




Fig. 5: FOSC 400 D closure

Technical Assistance Center (TAC)
 Tel.: 800.830.5056
 Email: TAC.Americas@commscope.com
 www.commscope.com

FOSC 400 and FOSC 450 are trademarks of CommScope Inc.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, CommScope makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. CommScope's obligations shall only be as set forth in CommScope's Standard Terms and Conditions of Sale for this product and in no case will CommScope be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of CommScope products should make their own evaluation to determine the suitability of each such product for the specific application.